

INSTRUCTIONS FOR CHANGING FROM POST MOUNT TO WALL MOUNT

1. Remove the collar from the lamp by loosening the screws inside the base of the lamp. (Keep the screws for use with the wall bracket)
2. Turn the valve a 1/4" left or right so the on/off adjustment will align with the access hole in the wall bracket.
3. Connect the copper feed line from the wall bracket to the valve of the lamp. (Tighten well)
4. Align the holes in the wall bracket with the holes in the base of the lamp and attach the wall bracket with the screws that were used for the collar making sure the valve access hole in the bracket is aligned with the valve on/off adjustment.

(IF HAVING TROUBLE ATTACHING WALL BRACKET, PROCEED TO STEP 5

5. Remove the (3) screws along the side of the wall bracket and take the bracket apart.
6. Take the one side of the wall bracket that has the valve access hole and attach it to the base of the lamp but do not tighten all the way. (Make sure the valve on/off adjustment is accessible through the access hole in the wall bracket)
7. Take the other side of the wall bracket and attach to the base of the lamp but do not tighten all the way.
8. Connect the 2 wall bracket sides and put the (3) screws back in to hold the wall bracket together.
9. Tighten the wall bracket to the lamp using the (2) screws in the base of the lamp.