

MAILBOX POST with NEWSPAPER HOLDER INSTALLATION INSTRUCTIONS

Check with your United States Postal Service for the height regulation of a rural mailbox.

1. Dig a hole approximately 24" deep x 12" wide.
2. Place the pedestal base over the hole and slide the post down through the base.
3. Back fill 2" -3" above ground level and push the base down to settle in the back fill.
4. Allow concrete to harden before assembling any of the accessories.
5. Attach the hardware to the mailbox(if not already attached).
7. Attach the mailbox to the newspaper holder using the screws that are supplied.
*The mailbox will sit forward on the newspaper holder, as shown in the photo to right. To allow this, drilling holes (using 3/16" drill bit) in the newspaper holder to align with the mailbox may be required.
8. If the cap is not already attached to the top of your post, attach the cap and secure it to the post by tightening the set screw in the side of the cap.

