

INSTRUCTIONS FOR CHANGING FROM WALL MOUNT TO PIER MOUNT

**ALWAYS MAKE CERTAIN THAT THE GAS SUPPLY IS TURNED OFF
AND YOUR LAMP HAS COOLED BEFORE ATTEMPTING ANY REPAIRS.**

- 1. Remove the wall bracket from the lamp by loosening the (2) screws inside the base of the lamp. (Keep the screws and the screen for use with the pier mount)**
- 2. Remove the copper feedline from the valve.**
- 3. Turn the valve a ¼” left or right so the on/off adjustment will align with the access hole in the pier mount.**
- 4. Place the screen under the lamp aligning the (2) holes for the screws.**
- 5. Attach the lamp to the pier mount using the (2) screws from above. (Make sure the valve on/off aligns with the valve access hole in the pier mount).**
- 6. Connect the copper feed line to the valve. (Tighten well)**

AMERICAN GAS LAMP WORKS

101 Hoeveler Street,
Springdale, Pa 15144

Toll Free: (855) 427-5483

Phone: (724) 274-7131

Fax: (724) 274-7009

www.AmericanGasLamp.com